

PREVENT WATER-SPOTTING WITH **RINSE AID**

Rinse Aid is a concentrated additive for dishwashers on crockery, glassware, cutlery, and combi-ovens to eliminate spots and streaks!

LET'S TALK WHAT IS RINSE AID?

Rinse Aid is a concentrated rinse additive that speeds up drying, eliminates streaking, and prevents water-spotting on machine-washed items. It reduces rinse water surface tension for even sheeting and quick dry-off without towels, phosphate-free and non-flammable for eco-friendly use in hard water.



Rinse Aid 5L **RIN5**
Rinse Aid 15L **RIN15**
Rinse Aid 20L **RIN20**

KEY BENEFITS



**QUICK DRYING
EFFICIENCY**

Speed up drying to save time effectively



**STREAK
ELIMINATION**

Eliminate streaking for flawless results instantly



**SPOT
PREVENTION**

Prevent water-spotting on dishware reliably



**HARD WATER
VERSATILITY**

Perform effectively even in hard water conditions

WHEN & HOW TO USE

Dishwashing Machines:
RINSE AID is injected by the electronic pumping equipment into the final rinse water in the dishwasher. The pump injects a correctly metered quantity with each rinse cycle. For machines with built-in RINSE AID dispensers.

Combi-Ovens:
RINSE AID can be used as part of the automatic cleaning cycle, follow the Manufacturer's Direction.



SCAN TO VIEW ME ONLINE

1800 301 302
sales@agar.com.au | www.agar.com.au

AGAR
The Chemistry of Cleaning™